

SUGGESTED PRINTER DRIVER MEDIA SETTINGS FOR PERMAJET DIGITAL PHOTO & FINE ART MEDIA

All the media settings shown below are suggested as being the most suitable to the PermaJet paper surface and are considered to be the most applicable in terms of the amount of ink being laid down by the printer.

Media names may vary slightly from model to model and so choose the closest matching name. Choosing different media settings to the ones below may alter the quality of your final printed image.

If you are using an existing PermaJet ICC profile, you will find the required media setting contained within the profile name as an abbreviation and the data in this table may then no longer be relevant.

PermaJet Media Name (alphabetical order)	Epson Printer Models using upto 6 inks	Epson Printer Models using 7 inks or more	Canon Printer Models	Other Printer Brands	Preferred Black Ink Type
Alpha Natural Rag 310	Epson Archival Matte	Velvet Fine Art Paper	Other Fine Art Paper	Matt Paper	Matte Black
Artist Watercolour 250	Epson Archival Matte	Velvet Fine Art Paper	Other Fine Art Paper	Matt Paper	Matte Black
Digital Transfer Film 165µ	Epson Premium Glossy	Epson Premium Gloss	Photo Paper Pro Platinum Gloss	Gloss Paper	Photo Black
Double-Sided Matt 250	Epson Archival Matte	Epson Archival Matte	Matte Photo Paper	Matt Paper	Matte Black
Double-Sided Oyster 285	Epson Premium Semi-Gloss	Epson Premium Semi-Gloss	Photo Paper Plus Semi-Gloss	Gloss Paper	Photo Black
Double-Sided Portfolio 230	Epson Archival Matte	Velvet Fine Art Paper	Other Fine Art Paper	Matt Paper	Matte Black
FB Distinction 320	Epson Premium Glossy	Epson Premium Gloss	Photo Paper Pro Platinum Gloss	Gloss Paper	Photo Black
FB Gold Silk 315	Epson Premium Semi-Gloss	Epson Premium Semi-Gloss	Photo Paper Plus Semi-Gloss	Gloss Paper	Photo Black
FB Matt 285	Epson Archival Matte	Velvet Fine Art Paper	Other Fine Art Paper	Matt Paper	Matte Black
FB Mono Gloss Baryta 320	Epson Premium Semi-Gloss	Epson Premium Lustre	Other Gloss Paper	Gloss Paper	Photo Black
FB Royal Gloss 310	Epson Premium Glossy	Epson Premium Glossy	Photo Paper Pro Platinum Gloss	Gloss Paper	Photo Black
FB Satin 310	Epson Premium Semi-Gloss	Epson Premium Semi-Gloss	Photo Paper Plus Semi-Gloss	Gloss Paper	Photo Black
Gallery Etching 310	Epson Archival Matte	Velvet Fine Art Paper	Other Fine Art Paper	Matt Paper	Matte Black
Gloss 271	Epson Premium Glossy	Epson Premium Gloss	Photo Paper Pro Platinum Gloss	Gloss Paper	Photo Black
Jupiter Matt Canvas 350	Epson Archival Matte	Velvet Fine Art Paper	Matt Paper - Heavyweight	Matt Paper	Matte Black
Matt Plus 240	Epson Archival Matte	Epson Archival Matte	Matte Photo Paper	Matt Paper	Matte Black
Matt Proofing 160	Epson Archival Matte	Epson Archival Matte	Matte Photo Paper	Matt Paper	Matte Black
Mercury Ultra White Canvas 405	Epson Archival Matte	Velvet Fine Art Paper	Other Fine Art Paper	Matt Paper	Matte Black
Museum Heritage 310	Epson Archival Matte	Velvet Fine Art Paper	Other Fine Art Paper	Matt Paper	Matte Black
Neptune Natural Matt Canvas 400	Epson Archival Matte	Velvet Fine Art Paper	Other Fine Art Paper	Matt Paper	Matte Black
Omega Rag 310	Epson Archival Matte	Velvet Fine Art Paper	Other Fine Art Paper	Matt Paper	Matte Black
Oyster 271	Epson Premium Semi-Gloss	Epson Premium Semi-Gloss	Photo Paper Plus Semi-Gloss	Gloss Paper	Photo Black
Photo Art Silk 290	Epson Archival Matte	Velvet Fine Art Paper	Other Fine Art Paper	Matt Paper	Matte Black
Photo Lustre 310	Epson Premium Lustre	Epson Premium Lustre	Photo Paper Pro Lustre	Gloss Paper	Photo Black
Portfolio Rag 220	Epson Archival Matte	Velvet Fine Art Paper	Other Fine Art Paper	Matt Paper	Matte Black
Portrait Rag 285	Epson Archival Matte	Velvet Fine Art Paper	Other Fine Art Paper	Matt Paper	Matte Black
Portrait White 285	Epson Archival Matte	Velvet Fine Art Paper	Other Fine Art Paper	Matt Paper	Matte Black
Saturn Semi-Gloss Canvas 350	Epson Premium Semi-Gloss	Epson Premium Semi-Gloss	Photo Paper Plus Semi-Gloss	Gloss Paper	Photo Black
Smooth Gloss 280	Epson Premium Glossy	Epson Premium Glossy	Photo Paper Pro Platinum Gloss	Gloss Paper	Photo Black
Smooth Pearl 280	Epson Premium Semi-Gloss	Epson Premium Semi-Gloss	Photo Paper Plus Semi-Gloss	Gloss Paper	Photo Black
Titanium Lustre 280	Epson Premium Semi-Gloss	Epson Premium Lustre	Photo Paper Pro Lustre	Gloss Paper	Photo Black
Ultra Pearl 295	Epson Premium Lustre	Epson Premium Lustre	Photo Paper Pro Lustre	Gloss Paper	Photo Black
Wall-Art Wallpaper Matt 170	Epson Archival Matte	Epson Archival Matte	Matte Photo Paper	Matt Paper	Matte Black

All recommendations are for your guidance only.

These settings are all derived from our own internal testing criteria and may be subject to change without prior notice. Visit our website regularly to check for media settings of new papers not listed here or for any changes.

